


AIR IMPACT WRENCH DIAGRAM - MODEL : SKIW0034



iw0034



AIR IMPACT WRENCH

MODEL : SKIW0034

SPARE PARTS LIST

No	Description	No	Description
1	Housing	22	Ball Bearing (EE-8)
	Valve Sleeve	23	Pin (3X14)
2	Air Inlet	24	Ball bearing (6202ZZ)
3	Exhaust Deflector	25	Pin (3X8)
4	Screw (M3XL8)	26	Bushing
5	Rubber Grip	27	Gasket
6	Hammer Cage	28	Front End Plate
7	O Ring (P10A)	29	Rear Cover
8	Anvil	30	Rotor
	Anvil	31	Rotor Blade
9	Hammer pin	32	Cylinder
10	Hammer	33	Rear End Plate
11	O Ring (P4)	34	Regulator Knob
12	Valve Stem	35	Screw & Spring Washer (M6XL25)
13	Valve Bushing	36	Inverted Retaining Ring (ISTW-16)
14	Spring Pin (2.5X22)	37	O Ring (AS014)
15	Spring	38	Housing Cover
16	Trigger	39	O Ring
17	O Ring (9X2)	40	Screw & Spring Washer (M6XL20)
18	O Ring (SM012)	41	Steel Ball (3.5mm)
19	O Ring (SM014)	42	Spring
20	Anvil Collar	43	Gasket
21	Set Screw (M4XL8)		